

## 1 1/2 in. DOUBLE CERAMIC FLAT IRON



For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

**CONAIR**

Instrucciones  
Model CS222 Series

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

### READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

**DANGER**—Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

**WARNING**—To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. Do not pull, twist, or wrap line cord around appliance, even during storage.
3. This appliance should not be used by, on or near children or individuals with certain disabilities.
4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.
6. Keep the cord away from heated surfaces.
7. Never use while sleeping.
8. Never drop or insert any object into any opening or hose.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Unit is hot when in use. Do not let heated surfaces touch eyes or skin.
11. Do not place the heated unit directly on any surface while it is hot or plugged in.
12. Never block the air openings of the appliance or place it on a soft surface such as a bed or couch, where the air openings may be blocked. Keep the air openings free of hair, lint and other debris.
13. Do not use an extension cord with this appliance.
14. Do not touch hot surfaces of the appliance. Use handles or knobs.
15. Do not attempt to touch the housing of your appliance near the straightening plates, as it is hot when in use.
16. This appliance is not a toy. Keep away from children.

**WARNING**—Do not use over or near washbasins, bathtubs, showers or other containers with water.



## SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This flat iron is intended for household use. This unit is designed to operate at 120V AC, 60Hz in model CS222NAL, and 220-240V AC, 50-60Hz for models CS222AR, CS222PE, CS222CL.

As additional protection, it is recommended to install a residual current device (RCD) with a rated residual operating current not exceeding 30mA on the electrical circuit feeding the bathroom. Ask your installer for advice.

### STRAIGHTENING BASICS

Plug the flat iron cord into any household outlet (120V AC or 220-240V AC in corresponding versions). Press ON/OFF button. The iron will heat up to the default temperature setting (338°F/170°C). Adjust temperature to desired level. Red light will blink until it reaches desired temperature setting and then becomes solid. Never leave your flat iron on and unattended. However, should you fail to turn the unit off, it will shut itself off automatically within 60 minutes at 60 Hz.

**NOTE: DO NOT USE THIS STYLING APPLIANCE ON HAIR EXTENSIONS.**

**WARNING: The flat iron's double ceramic-coated plates will get very hot within a few seconds and should not be placed in contact with the skin after the flat iron has been turned on.**

Start with a hair section that is 2 inches (5cm) wide

and no more than 1/2 inch (1.25cm) thick. Open the iron and place a hair section between the two hot plates, close to the scalp. Trap hair between the plates by firmly squeezing the handles together. While maintaining the tension, slowly pull the iron down along the hair section toward the ends. At the end of hair section, release the pressure on the handle and allow the hair to slide out. Repeat process on additional sections of hair until you achieve the hairstyle you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

Some experience is necessary when learning to use this flat iron. After using the iron several times, you will learn the ideal way to straighten and style your hair easily.

**NOTE:** Please refer to the temperature setting guide for heat settings.

### STYLING WITH DOUBLE CERAMIC-COATED PLATES

The easy-glide double ceramic surface is one of the latest technological advances in hair appliances. Hair glides over the ultra-smooth plate surface as you straighten, and styling product residue removes easily after each use. The unique plate surface creates antistatic smoothing action, helping smooth flyaways and frizzies for high-intensity shine and manageability. Ceramic evenly distributes heat to eliminate hot spots that can damage hair. This advanced, new technology leaves hair with a salon-perfect, silky smooth, shiny finish.

Turn your wrist up or under to create flips, add curl or more body.

### 2-IN-1 STRAIGHT OR VOLUME WITH A TOUCH OF CURL



### USING INSTANT HEAT, THE 5 VARIABLE TEMPERATURE SETTINGS

The 410°F high heat Uniform Heat Recovery System provides fast, professional salon styling results at home. This flat iron features Conair's Instant Heat technology. It quickly heats up to the temperature you've selected for your hair type and is then ready to use.

Within this Instant Heat technology are 5 temperature settings for every type of hair, from the finest to the curliest and most resistant.

### TEMPERATURE SETTING GUIDE

TEMP. CONTROL	HAIR TYPE
Low 266°F	Delicate, thin, easy-to-style hair
Medium 302°F	Average to thick or treated hair
Med-High 338°F	Thick or wavy hair
High 374°F	Hard-to-style hair
Maximum 410°F	Very resistant

### UNIFORM HEAT RECOVERY SYSTEM

Conair's professional salon standards of engineering provide you with a Uniform Heat Recovery System to maintain the flat iron at a constant temperature.

A constant surge of power ensures that heat is continuously delivered for optimal styling results, unlike other units, which lose heat during use. It provides consistent styling power so that every strand of hair is set with the same level of heat for uniform results and a perfect finish.


### STYLING WITH THE NEW EASY-GLIDE FLOATING PLATE

One plate of your new flat iron is designed with a little give, to "float" in the iron. This provides better contact with hair and eliminates gaps to achieve straighter results faster.

### ADD VOLUME AND SHAPE

To add flips and waves, secure ends in between plates and wrap hair around the outer housing. It's an easy way to add shape to straight styles.

### GET TO KNOW YOUR FLAT IRON



## USER MAINTENANCE

Your flat iron is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow it to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

### CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

### STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then store in a safe, dry location, out of reach of children. Do not jerk or strain cord at plug connections. Do not wrap the line cord tightly around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

**WARNING:  
IF YOU THINK  
THE POWER IS OFF  
WHEN THE SWITCH  
IS OFF,  
YOU'RE WRONG.**

KEEP AWAY FROM WATER



**ALWAYS UNPLUG  
SMALL APPLIANCES**

Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

### WARRANTY

Congratulations! You have purchased a guaranteed CONAIR product.

Warranty conditions:

1. The warranty is valid for 1 year from the date of purchase. To make it effective, you must submit the purchase invoice, which must be within the warranty period.
2. The warranty only applies to proven manufacturing defects. The product will be inspected and will be exchanged and/or repaired free of charge only if it presents an electrical or mechanical manufacturing defect within the warranty period.
3. The warranty does not apply:

- 3.1. If the product has been opened, disassembled or repaired by unauthorized personnel. The product should only be opened, inspected and/or repaired by the network of Authorized Service Technicians.
- 3.2. If the product has been used other than for domestic/household use, and/or for purposes for which it has not been designed.
- 3.3. If the damages are not manufacturing defects but damages caused by: impact, spills or spill residues on parts, insects, or any other external factors, as demonstrated during inspection; as well as damages caused by misuse, contrary to what is stated in the instruction manual.
- 3.4. If the damages or failures were caused by accidents, unforeseen or deliberate causes, electric shocks, voltage fluctuations and/or voltage 10% greater or lesser than the one indicated on the product's rating plate.
- 3.5. If the damages or failures were caused by accessories and parts broken or damaged during improper use of the product.

We recommend that you read the instruction manual.

### ONLY VALID IN ARGENTINA

**IMPORTANT:** KEEP THE INVOICE OF YOUR PURCHASE. ONLY ITEMS WITH THE INVOICE FROM THE SHOP THAT SOLD YOU THE ITEM ARE ACCEPTED.

Customer Service: Conair  
0810-888-2847 and 5300-5823  
Hours of operation: 8 am to 8 pm

### ONLY VALID FOR COLOMBIA.

**IMPORTANT:** PLEASE KEEP THIS CERTIFICATE OF WARRANTY, STAMPED BY THE ESTABLISHMENT WHERE THE PRODUCT WAS PURCHASED. YOU WILL BE REQUIRED TO PRESENT IT FOR ANY CLAIM UNDER THIS WARRANTY.

**Should the product fail to function properly after following all recommendations and instructions, please call our Service Center at 018000415385.**

Imported by:  
Continente S.A.S.  
Calle 69 # Via 40 -301, Barranquilla, Atl, Colombia  
Línea de Servicio al Cliente: 018000415385  
Email: sac@continente.com.co

### CHILE / PERÚ CERTIFICATE OF WARRANTY

Congratulations You have purchased a guaranteed CONAIR product. Conair and its brands: Cuisinart, Waring and CONAIR, extend the following service warranty, which entitles you to enjoy all the advantages that our network of Authorized Technical Services provides. Terms and Conditions of the Certificate of Warranty:

1. The warranty is valid from the date of purchase. To make it effective, the customer must present a proof of purchase and the Certificate of Warranty.
  - 2- The warranty only applies to proven manufacturing defects. The product will be inspected and will be exchanged and/or repaired only if it presents any electrical or mechanical manufacturing defect.
  - 3- The warranty does not apply:
- 3.1- If the product has been opened, disassembled or repaired by unauthorized personnel. The product should only be repaired by the network of Authorized Service Technicians.
  - 3.2- If the product has been used for purposes for which it has not been designed.
  - 3.3- If the damages are not manufacturing defects, e.g. impact damage, spill damage, insect damage or any other damages found during inspection. If the product has been misused, i.e. contrary to what is indicated in the instruction manual.
  - 3.4- If the damages were caused by accidents, accidental or deliberate acts, or voltage 10% greater or lesser than the one indicated on the product's rating plate.
  - 3.5- If the damages are due to the normal wear of parts and/or accessories during normal use.
  - 3.6- If the damages were caused to accessories and parts during improper use of the product.

\*\*We recommend that you read the instruction manual.

**IMPORTANT:** PLEASE KEEP THIS CERTIFICATE OF WARRANTY, STAMPED BY THE ESTABLISHMENT WHERE THE PRODUCT WAS PURCHASED. YOU WILL BE REQUIRED TO PRESENT IT FOR ANY CLAIM UNDER THIS WARRANTY.

MODEL #: CS222NAL, CS222CL, CS222PE, CS222AR

SERIAL #: \_\_\_\_\_

DATE OF PURCHASE: \_\_\_\_\_

INVOICE #: \_\_\_\_\_

THE WARRANTY PERIOD IS INDICATED ON THE PRODUCT BOX

VENDOR'S NAME AND STAMP:

CLIENT'S SIGNATURE AND ID #

- CS222NAL 120 V~ 60 Hz 56 W
- CS222AR 220-240 V~ 50-60 Hz 51 W
- CS222CL 220-240 V~ 50-60 Hz 51 W
- CS222PE 220-240 V~ 50-60 Hz 51 W

PLANCHA PARA CABELLO  
MARCA: CONAIR  
MODELO: CS222AR  
HECHO EN CHINA



ADVERTENCIAS DE SEGURIDAD MANUAL  
LEER MANUAL ANTES DE USAR

\* Marca TUV solo válida para CS222AR

©2019 Conair Corporation  
Origen: China  
Denominación: Plancha para Cabello  
Marca: Conair

**Argentina**  
Importa Distribuye y Garantiza Newsan S.A.  
Roque Pérez 3650-C1430FBX  
C.A.B.A. República Argentina

**Chile**  
Importado por: VALROD  
Avda. Apoquindo 5583,  
Of. 71 Las Condes  
Santiago, Chile

**Perú**  
Importado por: DICODA SAC  
Calle Los Laureles 365,  
San Isidro15073,  
Lima, Perú  
RUC: 20511662649

For info on any Conair or Infiniti Pro by Conair product call: 1-800-3-CONAIR or visit us on the web at: [www.conair.com/infiniti](http://www.conair.com/infiniti)



Manual and product references also available in: <http://www.conair.la>, <http://www.conair.com>

Please register this product at: [www.conair.com/registration](http://www.conair.com/registration)

### SERVICE CENTER

CONAIR CORPORATION  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

©2019 CONAIR CORPORATION

19IP065046

IB-15961A



## PLANCHA ALISADORA de CERÁMICA

de 38 mm (1 ½ in.)



**CONAIR**

Instrucciones  
Modelo CS222 Series

Para su seguridad y para disfrutar plenamente de este producto, siempre lea las instrucciones cuidadosamente antes de usarlo.

Para más información sobre los productos Conair o Infiniti Pro by Conair, llame al: 1-800-3-CONAIR o visítenos en: [www.conair.com/infiniti](http://www.conair.com/infiniti)



Manual y referencias de producto también disponibles en: <http://www.conair.la>, <http://www.conair.com>

Para registrar su producto, visítenos en [www.conair.com/registration](http://www.conair.com/registration)

### CENTRO DE SERVICIO


Conair Corporation  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

©2019 CONAIR CORPORATION

19IP065046

IB-15961A

## ADVERTENCIA — No usar este aparato cerca de las bañeras, duchas, recipientes u otros depósitos que contengan agua.



## GUARDE ESTAS INSTRUCCIONES DE OPERACIÓN

Para uso doméstico solamente. Este aparato a sido diseñado para funcionar a 120V AC, 50-60Hz en modelo CS222NAL y 220-240V AC, 50-60Hz en modelos CS222PE, CS222AR, CS222CL.

### FUNDAMENTOS DEL ALISADO

Conecte el aparato a una toma de corriente de 120V AC o 220-240V AC en versiones correspondientes). Presione el botón ON/OFF; el aparato se encenderá y calentará hasta la temperatura por defecto (338 °F/170 °C). Ajuste la temperatura al nivel deseado. El indicador luminoso rojo parpadeará hasta que la unidad alcance la temperatura seleccionada. Después, utilice los mango/asas y los botones/pelillas para manipular el aparato cerca de las placas se pone muy caliente durante el uso; no lo toque.

16. Este aparato no es un juguete; manténgalo alrededor del aparato, incluso para guardarlo.

15. El cuerpo del aparato cerca de las placas se empuja, para su seguridad, el aparato se apagará automáticamente después de 60 minutos (con corriente de 60 Hz).

### NOTA: NO UTILICE ESTE APARATO SOBRE CABELLO SINTÉTICO/EXTENSIONES.

**ADVERTENCIA.** Las placas se pondrán extremadamente calientes en segundos; evite el contacto con la piel después de encender el aparato.

Divida el cabello en secciones de 2 pulgadas (5 cm) de ancho por ½ pulgada (1,5 cm) o menos de espesor. Abra las placas y coloque una sección de cabello entre ellas, cerca del cuero cabelludo. Cierre las placas, manteniendo las placas bien cerradas. Siente el cabello tras llegar a las puntas. Repita el proceso con cada sección de cabello. Según la textura del cabello, puede que sea necesario repetir el proceso varias veces en cada sección.

### REVESTIMIENTO DE DOBLE CERÁMICA

El revestimiento de desluzamiento fácil con doble cerámica es lo último – y lo mejor – en tecnología de aparatos de peinadura. El cabello se desliza fácilmente entre las placas y éstas son muy fáciles de limpiar después de cada uso. La superficie única y un brillo intenso. La cerámica distribuye el calor uniformemente y evita los daños causados por el mismo. Esta tecnología permite obtener resultados profesionales, sedosos y brillantes.

Gire la muñeca hacia arriba o abajo para doblar las puntas hacia fuera/dentro, rizar o dar cuerpo.

### 2 EN 1 PARA ESTILOS LISOS O VOLUMEN CON RIZOS SUAVES



### CALENTAMIENTO INSTANTÁNEO, 5 AJUSTES DE TEMPERATURA

El sistema de recuperación del calor mantiene la temperatura constante (hasta 410 °F), para la temperatura constante (hasta 410 °F), para conseguir resultados profesionales en casa, rápidamente. Su plancha alisadora utiliza la tecnología del calentamiento instantáneo de Conair, lo que hace que alcance la temperatura deseada más rápidamente. Además, cuenta con 5 opciones de temperatura, para permitirle escoger la temperatura perfecta para su tipo de cabello, desde el más fino hasta el más grueso.

TIPO DE CABELLO	Cabello delgado, fino o dócil
Bajo 266 °F (130 °C)	Cabello normal a grueso o tratado
Medio 302 °F (150 °C)	Cabello grueso u ondulado
Medio-Alto 338 °F (170 °C)	Cabello resistente
Alto 374 °F (190 °C)	Cabello muy resistente
Máximo 410 °F (210 °C)	

### SISTEMA DE RECUPERACIÓN DEL CALOR

Su aparato también disfruta de los mismos estándares de calidad e ingeniería que los aparatos profesionales y cuenta con un sistema de recuperación del calor.

### 5 AJUSTES DE TEMPERATURA

Esta plancha alisadora está equipada con una placa "hotplate" para asegurar un mejor contacto con el cabello y producir resultados más lisos, más rápidamente. Para doblar las puntas y crear ondas, agarre las puntas del cabello entre las extremidades de las placas y enrollé en cabello alrededor de las placas cerradas. Es una manera fácil de dar volumen a cualquier peinado liso.

TIPO DE CABELLO	Cabello delgado, fino o dócil
Bajo 266 °F (130 °C)	Cabello normal a grueso o tratado
Medio 302 °F (150 °C)	Cabello grueso u ondulado
Medio-Alto 338 °F (170 °C)	Cabello resistente
Alto 374 °F (190 °C)	Cabello muy resistente
Máximo 410 °F (210 °C)	

### INSTRUCCIONES DE MANTENIMIENTO

Su aparato requiere poco mantenimiento. No necesita lubricación. Mantenga todas las aberturas libres de polvos y pelusas. Cuando sea necesario limpiarlo, desenchúfelo, permita que se enfríe y limpie la superficie exterior con un paño húmedo. En caso de mal funcionamiento, desconecte el aparato, permita que se enfríe y regrese a un centro de servicio autorizado, no trate de reparar el aparato.

### PRECAUCIÓN

NUNCA jale, retuerza ni doble mucho el cable. Nunca lo enrollé con fuerza alrededor del aparato; esto podría dañar la junta flexible que lo conecta al aparato, produciendo su ruptura o un cortocircuito. Revise el cable con frecuencia para asegurarse de que no está dañado. Deje de usar el aparato inmediatamente si el cable parece dañado o si el aparato deja de funcionar o funciona de manera intermitente.

Cuando no lo utiliza, su aparato es fácil de almacenar. Permita que se enfríe y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. No tireone ni retuerza el cable al nivel del enchufe.

No enrollé el cable alrededor del aparato. Permita que el cable cuelgue o que la junta para un almacenamiento fácil y seguro.




### FAMILIARÍSE CON SU PLANCHA ALISADORA

### GARANTÍA

¡Felicitaciones! Usted ha adquirido un producto CONAIR de calidad garantizada. Condiciones de garantía:  
1. La **garantía rige por 1 año a partir de la fecha de compra**. Para hacerla efectiva, por favor presente la factura de compra dentro del período de garantía.  
2. La garantía solamente aplica por fallas comprobadas en su funcionamiento. El artículo será revisado, y/o reparado gratuitamente por todo aquel defecto eléctrico o mecánico detectado durante la vigencia de la garantía.  
3. La garantía no tiene validez:  
3.1. Cuando el artículo haya sido abierto, desarmado o reparado por personal no autorizado. El artículo solamente debe ser abierto, inspeccionado y reparado por la red de Técnicos de Servicio Autorizados.  
3.2. Cuando el artículo haya sido utilizado para fines no domésticos y/o para trabajos para los cuales no ha sido diseñado.  
3.3. Cuando las fallas no sean defectos de fabricación sino daños causados por: impacto, derrames o residuos de derrames sobre piezas, insectos o cualquier otro factor externo, según se demuestre durante la inspección; así como daños causados por mal uso, contrario a lo establecido en el manual de instrucciones.  
3.4. Cuando los daños o averías hayan sido causados por accidentes, causas imprevistas o delibberadas, descargas eléctricas, fluctuaciones de tensión y/o tensión un 10 % superior o inferior a la indicada en la placa de especificaciones del producto.  
3.5. Cuando los defectos o daños o averías hayan sido causados por accesorios y piezas rotos o deteriorados durante el uso inadecuado del producto.  
Recomendamos leer el manual de instrucciones.

### MANTÉNGALO ALEJADO DEL AGUA



Todos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece bajo tensión aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchufe los aparatos eléctricos después de usarlos.

### SIEMPRE DESENCHUFE LOS APARATOS PEQUEÑOS