



FRIZZ FREE
1½ IN. TITANIUM
HOT AIR BRUSH

- TITANIUM CERAMIC -

Instructions & Styling Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

BC600 Series

IMPORTANT SAFETY INSTRUCTIONS

When using electric appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER — Any appliance is electrically live even when the switch is off. To reduce the risk of death or injury by electric shock:

1. Always unplug it immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.
6. As additional protection, it is recommended to install a residual current device (RCD) that has a rated operating fault current that does not exceed 30mA, in the electrical circuit that supplies the bathroom. Ask your installer for advice.

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children. Never use them in cribs, children's beds, strollers or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.



WARNING: Do not use over or near washbasins, bathtubs, showers or other containers with water.



To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. This appliance is not designed for use by persons (including children) with physical impairment, sensory or mental abilities, or lack of experience and knowledge, unless they have been supervised or instructed in the use of the appliance by a person responsible for your safety. Children must be supervised to ensure that they do not play with the appliance.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged or dropped into water. Return the appliance to an authorized service center for examination and repair.
5. Keep the cord away from heated surfaces. Do not wrap the cord around appliance.
6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
7. Never use while sleeping.
8. Never drop or insert any object into any opening or hose.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord with this appliance.
11. Do not direct hot air toward eyes or other heat-sensitive areas.

12. Attachments may be hot during use. Allow them to cool before handling.
13. Do not place appliance on any surface while it is operating.
14. Do not use with a voltage converter.
15. While using this appliance, keep your hair away from the air inlets.
16. This appliance is not a toy. Keep away from children.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This appliance is intended for household use. Use on Alternating Current.

NOTE: Do not use this styling appliance on hair extensions.

GETTING STARTED

This hot air brush is perfect for adding gorgeous volume and shine to styles. The titanium ceramic barrel gives fullness and body as you style, while the soft bristles create ultimate shine and smoothness.

ADVANCED IONIC TECHNOLOGY

Many aspects of modern living, including air conditioning, contact with man-made fibers and air pollution, contribute to a buildup of static electricity in the hair. Even brushing and towel-drying the hair can increase these levels, causing the surface of the cuticle to become rough.

Consequently, hair may have a dull appearance. Also, high levels of static charge cause hair to become flyaway and difficult to style.

The powerful ion generator produces a stream of negative ions that acts to neutralize the static charge, smoothing the scales on the cuticle for shiny, smooth and manageable hair, so you can achieve your desired style easily.

NOTE: The unit may produce a clicking sound at times, which is normal for a high-output ion generator.

TITANIUM CERAMIC TECHNOLOGY

The barrel of this premium hot brush is coated with a combination of the best materials for styling. A fusion of titanium and ceramic evenly distributes heat to gently style and protect hair from damaging hot spots. Hair wraps easily over the surface of this ultra-smooth barrel.

Barrel is exceptionally easy to clean, and you'll discover this combination of technologies leaves your hair silky smooth.

HEAT SETTINGS

There are 2 heat settings, plus a cool setting. Use the high heat setting for initial drying, and the low heat setting as hair begins to dry and for styling. Use the cool setting to set the style for long-lasting results. To select the low heat, slide the ON/OFF switch to the second position; the third position is for the high heat, and the first position is for the cool setting.

INSTRUCTIONS FOR USE

• If you have long or thick hair, you may find it quicker and easier to use a hair dryer first to rough-dry your hair and remove the excess moisture. For added volume, turn your head upside down as you dry.

• Once the hair is 80% dry, you should start to create your style using the styler.

MAXIMUM VOLUME AND BODY

1. Start by sectioning the hair.
2. To turn the appliance on, slide the ON/OFF switch to the correct heat setting for your hair.
3. Place the appliance into the hair, close to the roots, and brush through the section to remove any tangles.
4. For added root lift, hold the brush in place at the roots for a few seconds.
5. Use the cool setting to set style for long-lasting results.
6. After use, switch off and unplug the appliance.
7. Allow to cool before storing away.

CLEANING THE FILTER

1. Ensure the unit is switched OFF, unplugged, and cool.
2. Holding the handle of the unit, grip the rear filter and turn counterclockwise, as far as the rear filter will turn, and pull away from the unit.
3. Using a soft brush, clean any hair and other debris from the filter.
4. Replace the rear filter by aligning the grooves and turning clockwise, until the rear filter has clicked back into position.

GET TO KNOW YOUR HOT AIR SPIN STYLER



USER MAINTENANCE

Your appliance is virtually maintenance free. For proper performance, the appliance must be kept clean. Blocked or clogged air intake vents will cause the appliance to overheat. When cleaning is needed, unplug the cord and clean dust and lint from air intake openings with a small brush. The outer surface of the appliance should be wiped clean with a cloth only. If abnormal conditions occur, unplug the appliance, allow it to cool and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled or twisted. Never wrap the cord around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit.

Inspect the cord frequently for damage. STOP USE IMMEDIATELY if damage is visible or if unit stops or operates intermittently.

STORAGE — Important

When not in use, your appliance should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

WE RECOMMEND THAT YOU READ THE INSTRUCTION MANUAL.

IMPORTANT: KEEP YOUR PURCHASE RECEIPT. ONLY ARTICLES ACCOMPANIED BY THE INVOICE/ RECEIPT FROM THE STORE WHERE THE ITEM WAS PURCHASED WILL BE ACCEPTED.

Customer Service: Conair
0810-888-2847 and 5300-5823
Hours of operation: 8 am to 8 pm

CHILE / PERU / AL CERTIFICATE OF WARRANTY

Congratulations You have purchased a guaranteed CONAIR product. Conair and its brands: Cuisinart, Waring and CONAIR, extend the following service warranty, which entitles you to enjoy all the advantages that our network of Authorized Technical Services provides. Terms and Conditions of the Certificate of Warranty:

1. The warranty is valid from the date of purchase.
 1. The warranty is valid from the date of purchase. To make it effective, the customer must present a proof of purchase and the Certificate of Warranty.
 - 2-. The warranty only applies to proven manufacturing defects. The product will be inspected and will be exchanged and/ or repaired only if it presents any electrical or mechanical manufacturing defect.
 - 3-. The warranty does not apply:
 - 3.1-. If the product has been opened, disassembled or repaired by unauthorized personnel. The product should only be repaired by the network of Authorized Service Technicians.
 - 3.2-. If the product has been used for purposes for which it has not been designed.
 - 3.3-. If the damages are not manufacturing defects, e.g. impact damage, spill damage, insect damage or any other damages found during inspection. If the product has been misused, i.e. contrary to what is indicated in the instruction manual.
 - 3.4-. If the damages were caused by accidents, accidental or deliberate acts, or voltage 10% greater or lesser than the one indicated on the product's rating plate.
 - 3.5-. If the damages are due to the normal wear of parts and/or accessories during normal use.
 - 3.6-. If the damages were caused to accessories and parts during improper use of the product.
- **We recommend that you read the instruction manual.

IMPORTANT! PLEASE KEEP THIS CERTIFICATE OF WARRANTY, STAMPED BY THE ESTABLISHMENT WHERE THE PRODUCT WAS PURCHASED. YOU WILL BE REQUIRED TO PRESENT IT FOR ANY CLAIM UNDER THIS WARRANTY.

MODELS #: BC600 SERIES

SERIAL #: _____

DATE OF PURCHASE: _____

INVOICE #: _____

THE WARRANTY PERIOD IS INDICATED ON THE PRODUCT BOX

VENDOR'S NAME AND STAMP:

CLIENT'S SIGNATURE AND ID #

- BC600AL 125V~ 60Hz 500W
- BC600AR 220-240 V~ 50-60 Hz 450-500W
- BC600CL 220-240 V~ 50-60 Hz 450-500W
- BC600PE 220-240 V~ 50-60 Hz 450-500W

CEPILLO DE AIRE
MARCA: CONAIR
HECHO EN CHINA



ADVERTENCIAS DE SEGURIDAD MANUAL
LEER MANUAL ANTES DE USAR



Manual and product references also available at:
www.conairlatam.com or www.conair.com.

www.conairlatam.com

©2021 Conair Corporation
Origen: China

Argentina
Importa Distribuye y Garantiza Newsan S.A.
Roque Pérez 3650-C1430FBX
C.A.B.A. República Argentina

Chile
Importado por : VENTIS SPA
El Estero 5533, Condominio El Estero,
Penalolén, Santiago, Chile.
TEL: +(569)78088043/ +569 9
61855284/+56975374879
RUT : 76229287-4

Perú
Importado y Distribuido por: MACROTEL S.A.C.
Av. Arequipa 4130 Dpto. 205 Miraflores, Lima, Perú.
RUC : 20546288979

Colombia
Importado por: Continente S.A.S.
Calle 69 # Vía 40-301,
Barranquilla, Atl, Colombia
Línea Servicio al Cliente: 018000415385
sac@continente.com.co

WARNING:
IF YOU THINK THE
POWER IS OFF WHEN
THE SWITCH IS OFF,
YOU'RE WRONG.

KEEP AWAY FROM WATER

Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG
SMALL APPLIANCES