

1 in. DOUBLE CERAMIC FLAT IRON



For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

CONAIR®

Instrucciones
Model CS221 Series

USER MAINTENANCE

Your flat iron is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow it to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then store in a safe, dry location, out of reach of children. Do not jerk or strain cord at plug connections. Do not wrap the line cord tightly around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER — Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. Do not pull, twist, or wrap line cord around appliance, even during storage.
3. This appliance should not be used by, on or near children or individuals with certain disabilities.
4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.
6. Keep the cord away from heated surfaces.
7. Never use while sleeping.
8. Never drop or insert any object into any opening or hose.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Unit is hot when in use. Do not let heated surfaces touch eyes or skin.
11. Do not place the heated unit directly on any surface while it is hot or plugged in.
12. Never block the air openings of the appliance or place it on a soft surface such as a bed or couch, where the air openings may be blocked. Keep the air openings free of hair, lint and other debris.
13. Do not use an extension cord with this appliance.
14. Do not touch hot surfaces of the appliance. Use handles or knobs.
15. Do not attempt to touch the housing of your appliance near the straightening plates, as it is hot when in use.
16. This appliance is not a toy. Keep away from children.

WARNING — Do not use over or near washbasins, bathtubs, showers or other containers with water.



SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This flat iron is intended for household use. This unit is designed to operate at 120V AC, 60Hz in model CS221NAL, and 220-240V AC, 50-60Hz for models CS221AR, CS221PE, CS221CL.

As additional protection, it is recommended to install a residual current device (RCD) with a rated residual operating current not exceeding 30mA on the electrical circuit feeding the bathroom. Ask your installer for advice.

STRAIGHTENING BASICS

Plug the flat iron cord into any household outlet (120V AC or 220-240V AC en versiones correspondientes). Press ON/OFF button. The iron will heat up to the default temperature setting (338°F/170°C). Adjust temperature to desired level. Red light will blink until it reaches desired temperature setting and then becomes solid. Never leave your flat iron on and unattended. However, should you fail to turn the unit off, it will shut itself off automatically within 60 minutes at 60 Hz.

NOTE: DO NOT USE THIS STYLING APPLIANCE ON HAIR EXTENSIONS.

WARNING: The flat iron's double ceramic-coated plates will get very hot within a few seconds and should not be placed in contact with the skin after the flat iron has been turned on.

Start with a hair section that is 2 inches (5cm) wide and no more than ½ inch (1.25cm) thick. Open the

iron and place a hair section between the two hot plates, close to the scalp. Trap hair between the plates by firmly squeezing the handles together. While maintaining the tension, slowly pull the iron down along the hair section toward the ends. At the end of hair section, release the pressure on the handle and allow the hair to slide out. Repeat process on additional sections of hair until you achieve the hairstyle you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

Some experience is necessary when learning to use this flat iron. After using the iron several times, you will learn the ideal way to straighten and style your hair easily.

NOTE: Please refer to the temperature setting guide for heat settings.

STYLING WITH DOUBLE CERAMIC-COATED PLATES

The easy-glide double ceramic surface is one of the latest technological advances in hair appliances. Hair glides over the ultra-smooth plate surface as you straighten, and styling product residue removes easily after each use. The unique plate surface creates antistatic smoothing action, helping smooth flyaways and frizzies for high-intensity shine and manageability. Ceramic evenly distributes heat to eliminate hot spots that can damage hair. This advanced, new technology leaves hair with a salon-perfect, silky smooth, shiny finish.

Turn your wrist up or under to create flips, add curl or more body.

2-IN-1 STRAIGHT OR VOLUME WITH A TOUCH OF CURL



USING INSTANT HEAT, THE 5 VARIABLE TEMPERATURE SETTINGS

The 410°F high heat Uniform Heat Recovery System provides fast, professional salon styling results at home. This flat iron features Conair's Instant Heat technology. It quickly heats up to the temperature you've selected for your hair type and is then ready to use.

Within this Instant Heat technology are 5 temperature settings for every type of hair, from the finest to the curliest and most resistant.

TEMPERATURE SETTING GUIDE

TEMP. CONTROL	HAIR TYPE
Low 266°F	Delicate, thin, easy-to-style hair
Medium 302°F	Average to thick or treated hair
Med-High 338°F	Thick or wavy hair
High 374°F	Hard-to-style hair
Maximum 410°F	Very resistant

UNIFORM HEAT RECOVERY SYSTEM

Conair's professional salon standards of engineering provide you with a Uniform Heat Recovery System to maintain the flat iron at a constant temperature.

A constant surge of power ensures that heat is continuously delivered for optimal styling results, unlike other units, which lose heat during use. It provides consistent styling power so that every strand of hair is set with the same level of heat for uniform results and a perfect finish.


STYLING WITH THE NEW EASY-GLIDE FLOATING PLATE

One plate of your new flat iron is designed with a little give, to "float" in the iron. This provides better contact with hair and eliminates gaps to achieve straighter results faster.

ADD VOLUME AND SHAPE

To add flips and waves, secure ends in between plates and wrap hair around the outer housing. It's an easy way to add shape to straight styles.

GET TO KNOW YOUR FLAT IRON



WARRANTY

Congratulations! You have purchased a guaranteed CONAIR product.

Warranty conditions:

1. The warranty is valid for 1 year from the date of purchase. To make it effective, you must submit the purchase invoice, which must be within the warranty period.
2. The warranty only applies to proven manufacturing defects. The product will be inspected and will be exchanged and/or repaired free of charge only if it presents an electrical or mechanical manufacturing defect within the warranty period.
3. The warranty does not apply:
 - 3.1. If the product has been opened, disassembled or repaired by unauthorized personnel. The product should only be opened, inspected and/or repaired by the network of Authorized Service Technicians.
 - 3.2. If the product has been used other than for domestic/household use, and/or for purposes for which it has not been designed.
 - 3.3. If the damages are not manufacturing defects but damages caused by: impact, spills or spill residues on parts, insects, or any other external factors, as demonstrated during inspection; as well as damages caused by misuse, contrary to what is stated in the instruction manual.
 - 3.4. If the damages or failures were caused by accidents, unforeseen or deliberate causes, electric shocks, voltage fluctuations and/or voltage 10% greater or lesser than the one indicated on the product's rating plate.
 - 3.5. If the damages or failures were caused by accessories and parts broken or damaged during improper use of the product.

We recommend that you read the instruction manual.

ONLY VALID IN ARGENTINA

IMPORTANT: KEEP THE INVOICE OF YOUR PURCHASE. ONLY ITEMS WITH THE INVOICE FROM THE SHOP THAT SOLD YOU THE ITEM ARE ACCEPTED.

Customer Service: Conair
0810-888-2847 and 5300-5823
Hours of operation: 8 am to 8 pm

ONLY VALID FOR COLOMBIA.

IMPORTANT: PLEASE KEEP THIS CERTIFICATE OF WARRANTY, STAMPED BY THE ESTABLISHMENT WHERE THE PRODUCT WAS PURCHASED. YOU WILL BE REQUIRED TO PRESENT IT FOR ANY CLAIM UNDER THIS WARRANTY.

Should the product fail to function properly after following all recommendations and instructions, please call our Service Center at 018000415385.

Imported by:
Continente S.A.S.
Calle 69 # Via 40 -301, Barranquilla, Atl, Colombia
Línea de Servicio al Cliente: 018000415385
Email: sac@continente.com.co

CHILE / PERÚ CERTIFICATE OF WARRANTY

Congratulations You have purchased a guaranteed CONAIR product. Conair and its brands: Cuisinart, Waring and CONAIR, extend the following service warranty, which entitles you to enjoy all the advantages that our network of Authorized Technical Services provides. Terms and Conditions of the Certificate of Warranty:

1. The warranty is valid from the date of purchase. To make it effective, the customer must present a proof of purchase and the Certificate of Warranty.
- 2- The warranty only applies to proven manufacturing defects. The product will be inspected and will be exchanged and/or repaired only if it presents any electrical or mechanical manufacturing defect.
- 3- The warranty does not apply:

3.1- If the product has been opened, disassembled or repaired by unauthorized personnel. The product should only be repaired by the network of Authorized Service Technicians.

3.2- If the product has been used for purposes for which it has not been designed.

3.3- If the damages are not manufacturing defects, e.g. impact damage, spill damage, insect damage or any other damages found during inspection. If the product has been misused, i.e. contrary to what is indicated in the instruction manual.

3.4- If the damages were caused by accidents, accidental or deliberate acts, or voltage 10% greater or lesser than the one indicated on the product's rating plate.

3.5- If the damages are due to the normal wear of parts and/or accessories during normal use.

3.6- If the damages were caused to accessories and parts during improper use of the product.

**We recommend that you read the instruction manual.

IMPORTANT: PLEASE KEEP THIS CERTIFICATE OF WARRANTY, STAMPED BY THE ESTABLISHMENT WHERE THE PRODUCT WAS PURCHASED. YOU WILL BE REQUIRED TO PRESENT IT FOR ANY CLAIM UNDER THIS WARRANTY.

MODEL #: CS221AR, CS221CL, CS221PE, CS221NAL

SERIAL #: _____

DATE OF PURCHASE: _____

INVOICE #: _____

THE WARRANTY PERIOD IS INDICATED ON THE PRODUCT BOX

VENDOR'S NAME AND STAMP:

CLIENT'S SIGNATURE AND ID #

- CS221NAL 120 V~ 60 Hz 45 W
- CS221AR 220-240 V~ 50-60 Hz 43 W
- CS221CL 220-240 V~ 50-60 Hz 43 W
- CS221PE 220-240 V~ 50-60 Hz 43 W

PLANCHA PARA CABELLO
MARCA: CONAIR
MODELO: CS221AR
HECHO EN CHINA



ADVERTENCIAS DE SEGURIDAD MANUAL
LEER MANUAL ANTES DE USAR

* Marca TUV solo válida para CS221AR

©2019 Conair Corporation
Origen: China
Denominación: Secador para Cabello
Marca: Conair

Argentina
Importa Distribuye y Garantiza Newsan S.A.
Roque Pérez 3650-C1430FBX
C.A.B.A. República Argentina

Chile
Importado por: VALROD
Avda. Apoquindo 5583, Of. 71 Las Condes
Santiago, Chile

Perú
Importado por: DICODA SAC
Calle Los Laureles 365,
San Isidro15073,
Lima, Perú
RUC: 20511662649

For info on any Conair or Infiniti Pro by Conair product call: 1-800-3-CONAIR or visit us on the web at: www.conair.com/infiniti



Manual and product references also available in: <http://www.conair.la>, <http://www.conair.com>

Please register this product at: www.conair.com/registration

SERVICE CENTER

CONAIR CORPORATION
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

©2019 CONAIR CORPORATION

19IP065048

IB-16428A

