材质：105g铜版纸

尺寸：105 x 148.5mm

印刷：单黑双面印刷

装订方式：骑马钉装订

（封面封底内页留白, 最后多一页留空白）

Ventis SpA.
Camino Lo Boza 107 A09.
Pudahuel. Santiago. Chile.
RUT 76229287-4
support@caulife.com
www.caulife.com

Made in China

OZŪ

User Manual
Manual de Instrucciones

Sillón de Masaje
Bergere Zero Gravity

Modelos: UM-305/UM-306

Contents

English ..... 01 - 17
Español ..... 18 - 34

Thank you for purchasing the OZŪ UM-305/UM-306 Bergere Zero Gravity. Please read this use and care manual thoroughly and keep it in a safe place for future reference. If you need any assistance, please contact our customer support team.

IMPORTANT SAFETY INSTRUCTIONS:

DANGER - To reduce the risk of electric shock: Always unplug this massage chair from the electrical outlet immediately after use and before cleaning.

WARNING - To reduce the risk of burns, fire, electric shock or injury to persons:
►An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
►Unplug from outlet during thunder or lightening storms, and before putting on or taking off parts.
►Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
►Check that the power voltage stated on the rating label corresponds to your local electricity supply.
►Do not use a damp hand to unplug the cord to avoid electric shock.
►Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
►Do not drag the cord, or reach to the front plastic end to unplug it.
►Do not squeeze,over bend , pull hard, twist the cord and please keep the cord away from heated surfaces.
►Do not carry this appliance by supply cord or use cord as a handle.
►To disconnect, turn all controls to the OFF position, then remove plug from outlet.
►The appliance is only to be used with the power supply unit provided with the appliance.
►The appliance must only be supplied at safety voltage corresponding to the marking on the appliance.

►If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
►Do not use the appliance if abnormal sound is heard.
►Do not massage areas that are swollen, inflamed or covered with skin eruptions.
►Connect the massage chair to a properly grounded outlet.

SAFETY PRECAUTIONS

►This product is designed for personal in-home use. Commercial use will void warranty.
►Do not use the appliance when the upholstery or seat is removed, or when the appliance is not properly installed. This may cause injury or malfunction.
►Do not massage the same area for more than 5 minutes at a time as it may result in excessive stimulation and adverse effects.
►Do not use the appliance in an hour after meal.
►Do not allow children or pets to play around the device, behind the backrest or under the seat to avoid accidental injuries.
►Do not use the device when your body is wet, and please do not operate with wet hands.
►Stop using immediately if you experience any discomfort.
►The appliance is not intended for self diagnosis or self-treatment of conditions that should be managed by a qualified health care provider.
►Please consult your doctor before use if you are pregnant or menstruating.
►The suggested usage duration is 20 minutes.

NAMES AND FUNCTIONS OF PARTS:



1. Head cushion
2. Bluetooth Speaker
3. Upper arm air pressure component
4. Arm air pressure component
5. Manual controller or mobile phone placement slot
6. USB charging port
7. Seat cushion
8. Leg rest
9. Foot rest
10. Backrest
11. Armrest
12. Handrail shortcut key
13. Embedded lamp
14. Handrail decoration
15. Side cover
16. Back cover
17. Manual controller
18. Drive box cover
19. Move pulley
20. Power cord and plug
21. Safety box
22. Wire socket of hand controller
23. Power switch
24. Power line socket

Function

- This product design has a set of massage manipulators that can walk up and down, four-wheel drive and a silent operation.
- There are five massage techniques: finger pressing, kneading, tapping, tapping and kneading at same time.
- Equipped with shoulder automatic positioning detection.
- Automatic massage functions: automatic massage includes 12 kinds of automatic massage functions, including comfortable massage, relaxing massage, traction massage, shoulder and neck massage, back and waist massage, whole body massage, Protection of vertebral massage, fatigue recovery, stretching muscles and activating collaterals, beautiful buttock shaping, soothing sleep and full air pressure.
- Equipped with upper body manual massage function (The whole body, fixed pointand local three massage parts are selected, and the speed of each massage manipulation can be adjusted with five speed. In fixed point and local state, the manipulator can adjust the position up and down; When tapping, pressing andpercussion massage, the width of the massage ball can be wide, medium ornarrow.
- Pneumatic massage function three modes and three levels of intensity selection: Body pressure, arm pressure, leg pressure.
- It is equipped with foot roller massage function.
- With leg frame with step-free adjustable function, suitable for different height use.
- With back heat treatment function: carbon fiber as far infrared heat source.
- Under the backrest frame, the backrest adopts slide rail technology to keep the zero space against the deviation wall all the time, so as to save the space tothe greatest extent.
- Backrest frame guide adopts curve guide technology, which completely conformsto the curve of human back, and can enjoy massage from head to thigh.

- Music playback system, 3D Bluetooth speakers are built into left and right upper arms. Usethe Bluetooth function of the smart device to play music wirelessly.
- The left handrail is equipped with five kinds of handrail shortcut keys, such as openkey, calf frame lifting key, automatic mode key, linkage adjusting key andzero gravity key.
- The right handrail is equipped with USB charging function.
- The handrails on both sides are equipped with ice blue atmosphere lamp.
- LCD Color screen controller.
- Shutdown automatic sitting function, manipulator automatic reset function.

Method of usage

LCD: display all massage functions.



1. LCD: Display all massage functions.
2. Power switch: Turn on or off all massage functions.
3. Pause \ run button: Pause or run all massage functions.
4. Timing key: Timing time adjustment
5. Automatic reclining key: There are three automatic reclining modes, which can automatically switchaccording to your own needs.
6. Footrest up key: Adjust footrest up.
7. Automatic massage button: Please refer to page 10 of this manual for details.
8. Air pressure mode key: Turn on/off air pressure massage function (please refer to page 11 of this manualfor details)
9. Manual massage key: Please refer to page 11 of this manual for details.
10. Foot roller key: Please refer to page 11 of this manual for details.
11. Shoulder adjustment key: Manual adjustment of human shoulder position massage finger pressure point.
12. Up key: Adjust backrest frame rise and calf frame drop.
13. Calf frame down key: Adjust calf frame down.
14. Lie down key: Adjust backrest frame to drop and calf frame to rise.
15. Air pressure intensity key: Adjust air pressure intensity function.
16. Heating key: On/off heating massage function.

FEATURES AND PRODUCT HIGHLIGHTS:

Using The Massage Modes

1. Switch power supply on

2. Start to massage
①. Press the power button to start the massage.
②. Leg frame and back frame will automatically angle to lie down, waiting for the selection of massage function (select an automatic function). In the sitting posture adjustment for more than 3 minutes without operation, will automatically perform shutdown and sitting.
③. After selecting the function of automatic mode, the automatic detection of human shoulder position and massage finger pressure point shall be carried out first, and wait for the completion of the detection.
④. If the detected shoulder position is deviated from the actual shoulder position, adjust the upper and lower keys of the shoulder position to the appropriate position.The shoulder position has 10 positions. No shoulder position adjustment within 10 seconds, then automatically enter the massage function.

Button	Description	Display
▲	Move the massage balls upward to a suitable position	
▼	Move the massage balls downward to a suitable position	

Place in a shoulder massage and acupressure point detection process, (manual device screen display shoulder position adjust icon and hear manual device "click" sound, and then key shoulder position which can adjust the position of shoulder), now has 12 can be automatically massage function keys (comfortable massage, massage, traction massage easily, massage neck, back, waist massage whole body massage, protecting vertebral massage, fatigue recovery, relaxes the muscles and stimulate blood circulation, shaping beautiful buttock, a good sleep, full pressure) in any key and enter the massage function (skip step 5).

③. Select the massage function, massage.

Massage Modes

-Automatic Massage

Function	Button	Description	Display
Automatic massage	Comfort	Comfort: The most comfortable massage experience.	F1 Auto
	Relax	Easy: the depth of the soft and comfortable massage, relieve body fatigue	F2 Auto
	Stretch	Frame and backrest frame rise and fall, and air pressure massage, and stretch or traction on the leg, remove fatigue, redfore vitality.	F3 Auto
	Pressure	Shoulder & neck: focus on shoulder and neck massage.	F4 Auto
	Backpat	Back &waist: to back waist massage focus.	F5 Auto
		Full body massage: deep massage to rejuvenate the body.	A1 Auto
		chiropractic massage: focus on chiropractic massage, relax body and mind.	A2 Auto
		Fatigue recovery: improve the whole body fatigue pain, for the back, limbs to achieve relaxation and improve microcirculation, quickly relieve fatigue.	A3 Auto
	Warm	Meridians massage: dredge meridians, quickly improve the body's microcirculation, enhance immunity.	A4 Auto
		Beautiful buttock model: be aimed at buttock and thigh effective massage, beautify body shape, reduce the accumulation of redundant adipose body.	A5 Auto
		Sleep peacefully massage: through the twelve major health acupoints massage to help the body recuperate balance, quickly improve sleep, improve sleep quality.	A6 Auto
		All pressure: focusing on the whole body pressure massage to fully relax the body, to the depth of the body massage, fully relieve fatigue and pain of the body	A7 Auto

- Upper Body Manual Massage

Function	Button	Massage ball adjustment	Display
Technique	Mode	Shiatsu: speed, width.	
		Knead: speed.	
		Beat: speed, width.	
		Knead pat: speed.	
		Knock: speed, width.	
Speed	Speed	5 speed adjustable.	
Width	Width	The width of the third gear can be adjusted.	
Back stretch		Fixed position and spot massage.	H0
		Small area local round trip massage.	H1
		A round trip massage.	H2
	▲	Massage position adjustment (in fixed point and local mode, massage position can be adjusted).	Manipulator uplink
	▼		Manipulator descending.

- Pneumatic massage

Function	Button	Description	Display
Air Pressure Mode	Air Pressure	Full pressure: air pressure massage on arms, legs and feet.	Arm Leg Foot
		Arm: air pressure massage with the arm as the focus.	Arm
		Leg: barometric massage for leg, foot.	Foot
Intensity	Intensity	Adjustable in three levels.	Arm Leg Foot

-Foot roller massage

Function	Button	Description	Display
Foot Roller	Foot Roller	Press this button to turn on or off the foot roller massage, and has a weak, medium, dfrong three levels of intensity can be adjusted to close the four dlates of cycle switching.	

- Heated massage

Function	Button	Description	Display
Heat	Heating	Press this button to turn on or off the back far infrared hyperthermia. Turn on 3 minutes later Have a warm.	

-Pause/start massage button

Function	Button	Description	Display
Pause/start	II	Press this button in the process of massage, and all massage movements will be suspended urgently when time continues to countdown), and then press this key to resume all before suspension massage.	II

- Adjust Lying Angle

Function	Button	Description
Set Up		Al pressionar esta botón, el respaldo lentamente se levantará y el marco de la pantorrilla lentamente descenderá y se emitirá un pitido hasta que llegue a la parte más alta. Presione esta botón de nuevo mientras está sentado para detener el movimiento
Lay Down Key		Presione esta tecla y el respaldo lentamente descenderá y el marco de las pantorrillas lentamente se levantarán y se emite un pitido hasta que se detiene. Presione esta tecla de nuevo durante el proceso de recolbarse para detener el movimiento.
Calf Rise up		Presione esta tecla y el respaldo lentamente descenderá y el marco de la pantorrilla lentamente se levanta y emita un pitido hasta que alcanza lo más alto y se detiene. El movimiento se detiene al soltar el botón
Calf Go down		Presione esta tecla y el respaldo lentamente se levanta y emita un pitido hasta que alcanza lo más bajo y se detiene. El movimiento se detiene al soltar el botón
Lie Down Automatically		Presione este botón cuando quiera cambiar a uno de los modos de recolbado automático. Hay 3 modos.

-Other manual functions

Function	Button	Description	Display
Timing	Timer	Time adjustment, every time to press will add 5 minutes, can not exceed 30 minutes, if more than 30 minutes return to the minimum time value.	20min

Handrail shortcut keys

The Left Arm



1. Turn on the key: open the massage chair.
2. Calf lift key: adjust the calf up or down.
3. Automatic key: enable automatic massage function.
4. Linkage adjustment key: linkage adjustment backrest frame lifting adjustment.
5. Zero-gravity key: adjust to the zero-gravityAngle of the massage chair.

Function	Description
	Power button: press this button to turn on or off all massage functions.
	Linkage up: press and hold this key to lift the backrest slowly and lower the calf frame slowly. Release it to stop lifting the backrest or lowering the calf, and the leg will automatically detect the length of the foot.
	Linkage down: press and hold the key to lower the backrest slowly while the calf frame rises slowly. Release the key to stop the backrest falling or the calf rising, and the leg will automatically detect the length of the foot.
Zero	Zero gravity key: every time you press the key, automatically adjust the position of calf frame and backrest frame to zero gravity position. There are two types of zero-gravity lying mode, which can be rotated.
	Calf up key: lift the key up calf slowly, release will drop calf up.
	Calf frame down key: press the key down calf frame slowly down, release will drop calf frame down.
AUTO	Automatic mode key: press each time, automatic massage function switch.

The Right Arm



Bluetooth Player Operation

1. Enter the smart device manual and open the Bluetooth function to search the new Bluetooth devices .
2. Find the Bluetooth named like (MCM-XXXX),choose it to pair with the chair.
3. Turn on the Music Player in the smart device .

Turn off the power and stop massage

- When pressing the power button during the massage, it will stop all the massage functions immediately, the backrest and footrest will go back to the default posit on.And when the massage time up, the massage hand will go back to the default position, all the massage function will stop, the backrest and footrest will not go back to the default position.
- Cut off the power of the whole machine. Figure (switch power off)



PREPARATION BEFORE USE:

The calf installation

1. After connecting the air hose and the wire harness on the calf and the massage chair, unlie the fixed line belt and insert the connecting part into the frame. (Figure 1).
2. Place the calf fixing block on the two sides of the round tubes of the calf (Figure 2).



3. Hang the calf of the fixed block on the massage chair frame hook (Figure 3).
4. Then use 4 (each side two pcs) M4 screws to fasten the calf to the massage chair, check whether there is any abnormality, whether the pipeline is folded or not, and finish the installation (Figure 4).



Head cushions and backrest pad

The head cushion allows you to control the intensity of the neck and shoulder massage. You can decide whether to use the head cushion (Recommend to use). The backrest cushion and the backrest is connected by zipper (1). head cushion and the backrest cushion connected by the Velcro as show in the illustration (2).



Floor Protection

- Put the heavy massage chairs on the wood floor for a may damage the floor, so please place a carpet or other object to avoid this damage.

Caution: Do not move the chairs with its wheels on wood floor, rough ground or in a narrow space. Two people are required to lift the chair. During the lifting period, take the calf rest end sealing plate and backrest cover grooves as the force-bearing point (please do not lift armrest directly.)

Note: During movement you must turn off the power first and then unplug the power cord and the controller cord.

STORAGE AND MAINTENANCFE:

Maintenance

- This product should be maintained by certain appointed agents, users are prohibited to disassemble or maintain by themselves.
- Please don't forget to cut the power after usage.
- Don't use this product if the socket looses.
- If this product will be left unused for long, please curl up the wires and reserve this product in dry and dustless environment.
- Don't reserve this product under high temperature or near fire and avoid longtime direct sunshine.
- If the detachable cord / supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a Hazard.
- Please clean this product by dry cloth. Don't use thinner, benzene or alcohol.
- The mechanical components of this product are specially designed and made, it is not necessary to be specially maintained.

- Don't roll or pull this product above uneven ground, it should be lifted before moving.
- Please use it intermittently; don't make this product work continuously for a long time.

TROUBLESHOOTING:

Problems	Possible causes	Actions
Controller is not function properly	The plug and socket is not connected	Check the plug and socket if they are connected strongly and make sure the switch is turned on
The chair stops without notice	Overheat will make the temperature protector automatically power-off the chair	Use the chair after 30 minutes to avoid overheating
Not working	The plug is in loose connection.	Plug in the socket. Switch on the power.
	The switch is on "Off" position.	
Beeping sound when the massage knots run up and down.	The guide rail is short of lubricating oil after long use.	Apply oil from the right guide rail tank to the side of the guide rail.

If you still have problem with the machine, please contact our customer support team.

SPECIFICATIONS:

Model Number: UM-305/UM-306
Product Name: Bergere Zero Gravity
Rated Frequency: 50-60Hz
Power Consumption: 120W
Rated Voltage: 220-240V~
Rating Time: 5/10/15/20/25/30 Minutes
Materials: PVC, PA, steel parts and electric & electron parts
Gross/Net Weight: 108/88 kg
Dimension: 120*X*130 cm
Safety Design: Class I

WARRANTY AND CUSTOMER SERVICE:

For questions, assistance, support, or warranty claims, please contact us at the address that corresponds with your region. Please have in hand your ticket or invoice and product model number when contacting us.

Gracias por adquirir el sillón de masaje OZū Bergere Zero Gravity UM-305/UM-306. Lea este manual de uso y cuidado detenidamente y guárdelo en un lugar seguro para futuras consultas. Si necesita ayuda, comuníquese con nuestro equipo de atención al cliente.

INSTRUCCIONES DE SEGURIDAD IMPORTANTES:

PELIGRO: para reducir el riesgo de descargas eléctricas: desenchufe siempre este sillón de masaje del tomacorriente inmediatamente después de su uso y antes de limpiarlo.

ADVERTENCIA: para reducir el riesgo de quemaduras, fuego, descargas eléctricas o lesiones a las personas:
►Un aparato nunca debe dejarse desatendido cuando está enchufado. Desconéctelo del tomacorriente cuando no esté en uso y antes de colocar o quitar piezas.
►Desconéctelo del tomacorriente durante tormentas eléctricas o relámpagos, y antes de ponerse o quitarse piezas.
►Nunca opere este electrodoméstico si tiene un cable o enchufe dañado, si no funciona correctamente, si se ha caído o dañado, o si se ha caído al agua. Devuelva el aparato a un centro de servicio para que lo examinen y lo reparen.
►Compruebe que el voltaje de alimentación indicado en la etiqueta de clasificación corresponda con el suministro eléctrico local.
►No desenchufe el cable con las manos húmedas para evitar descargas eléctricas.
►No permita que los niños o las mascotas jueguen alrededor del dispositivo, la detrás del respaldo ni debajo del asiento para evitar lesiones accidentales.
►No utilice el dispositivo cuando su cuerpo esté mojado y no lo opere con las manos mojadas.
►Deje de usarlo inmediatamente si experimenta alguna molestia.
►El aparato no está diseñado para el autodiagnóstico o el autotratamiento de afecciones que deben ser manejadas por un proveedor de atención médica calificado.
►Consulte a su médico antes de usar si está embarazada o menstruando.
►La duración de uso sugerida es de 20 minutos.

►Este aparato solo debe utilizarse con la fuente de alimentación suministrada con el mismo.
►Este aparato solo debe alimentarse con la tensión de seguridad correspondiente o lo marcado en el mismo.
►Si el cable de alimentación está dañado, debe ser reemplazado por el fabricante o su agente de servicio o una persona calificada similar para evitar un peligro.
►No utilice el aparato si se ove un sonido anormal.
►No masajee áreas hinchadas, inflamadas o cubiertas con erupciones cutáneas.
►Conecte el sillón de masaje solo a un tomacorriente debidamente conectado a tierra.

PRECAUCIONES DE SEGURIDAD

►Este producto está diseñado para uso personal en el hogar. El uso comercial anulará la garantía.
►No utilice el electrodoméstico sin la tapicería o el asiento, o cuando el electrodoméstico no esté instalado correctamente. Esto puede causar lesiones o mal funcionamiento.
►No masajee la misma área durante más de 5 minutos seguidos, ya que puede provocar una estimulación excesiva y efectos adversos.
►No utilice el aparato sino hasta pasada una hora después de las comidas.
►No permita que los niños o las mascotas jueguen alrededor del dispositivo, la detrás del respaldo ni debajo del asiento para evitar lesiones accidentales.
► No utilice el dispositivo cuando su cuerpo esté mojado y no lo opere con las manos mojadas.
►Deje de usarlo inmediatamente si experimenta alguna molestia.
►El aparato no está diseñado para el autodiagnóstico o el autotratamiento de afecciones que deben ser manejadas por un proveedor de atención médica calificado.
►Consulte a su médico antes de usar si está embarazada o menstruando.
►La duración de uso sugerida es de 20 minutos.

NOMBRES Y FUNCIONES DE LAS PIEZAS:

1. Cojín para la cabeza
2. Altavoz Bluetooth
3. Componente de presión de aire de la parte superior del brazo
4. Componente de presión de aire del brazo
5. Espacio para colocar el control manual o el teléfono móvil
6. Puerto de carga USB
7. Cojín del asiento
8. Reposapiernas
9. Respaldo
10. Respaldo
11. Apoyabrazos
12. Tecla de acceso directo de la barandilla
13. Lámpara empotrado
14. Decoración del pasamanos
15. Cubierta lateral
16. Cubierta trasera
17. Control manual
18. Tapa de la caja de transmisión
19. Polea para mover
20. Cable de alimentación y enchufe
21. Caja de seguridad
22. Entrada del cable del control manual
23. Interruptor de encendido
24. Toma de corriente

Funciones

- Este producto integra en su diseño un conjunto de nudos de masaje que pueden subir y bajar, tracción en las cuatro ruedas y un mecanismo silencioso.
- Integra cinco técnicas de masaje: Presión, simulación de masaje con los dedos, amasamiento, golpeteo y golpeteo con amasamiento simultáneo.
- Equipado con detección de posicionamiento automático de hombros.
- Con 12 tipos de funciones automáticas de masaje que incluyen: masaje cómodo, masaje relajante, masaje de tracción, masaje de hombros y cuello, masaje de espalda y cintura, masaje de cuerpo entero, masaje de protección vertebral, recuperación post-fatiga, estiramiento de músculos y activación de colaterales, modelador de glúteos, sueño relajante y presión de aire completo.
- Equipado con función de masaje manual en la parte superior del cuerpo (cuerpo entero, punto fijo y selección demasaje en tres partes localizadas) y la velocidad de cada tipo de masaje se puede elegir de entre cinco niveles. En los ajustes de punto fijo y masaje local el masaje se puede ajustar hacia arriba o hacia abajo. Cuando se selecciona masaje por golpeteo, por presión y percusión, el rango del rodo de masaje puede ser ancho, mediano o estrecho.
- Función de masaje neumático tres modos y tres niveles de intensidad a elegir. Presión en el cuerpo, presión en los brazos, presión en las piernas.
- Equipado con función de masaje por rodillos en los pies.
- Función de ajuste continuo del marco de las piernas, que se adecúa para distintas estaturas.
- Con función de tratamiento térmico para espalda: fibra de carbono como fuente de calor infrarrojo lejano.
- Debajo del marco del respaldo, el respaldo adopta la tecnología de rel deslizante para mantener el espacio cero contra la pared en todo momento, para ahorrar espacio en la mayor medida.
- La guía del marco del respaldo adopta la tecnología de guía curva, que se ajusta completamente a la curvatura de la espalda humana para que pueda disfrutar de un masaje de la cabeza a los muslos.
- Sistema de reproducción de música, los altavoces 3D Bluetooth están integrados en la parte superior izquierda y derecha de los brazos. Utilice la función Bluetooth del dispositivo inteligente para reproducir música de forma inalámbrica.
- La barandilla izquierda está equipada con cinco tipos de teclas de acceso directo, como tecla de inicio, tecla de elevación del bastidor de pantorrillas, tecla de modo automático, tecla de ajuste de vaciléje y tecla de gravedad cero.
- La barandilla derecha está equipada con función de carga USB.
- Las barandillas en ambos lados están equipadas con lámpara de atmósfera azul hielo.
- Control de pantalla LCD a color.
- Función de sentido automático al apagarse, función de reinicio automático del masajeador.

Forma de usar



1. LCD: muestra todas las funciones de masaje.
2. Interruptor de encendido: enciende o apaga todas las funciones de masaje.
3. Botón Pausa \ Ejecutar: pausa o ejecuta todas las funciones de masaje.
4. Tiempo de temporizador: ajuste del tiempo del temporizador
5. Tecla de reclinación automática: hay tres modos de reclinación automáticos, que pueden cambiar automáticamente según sus propias necesidades.
6. Tecla de reposapiés hacia arriba: ajuste del reposapiés hacia arriba.
7. Botón de masaje automático: consulte la página 10 de este manual para obtener más detalles.
8. Tecla de modo de presión de aire: enciende / apaga la función de masaje de presión de aire (consulte la página 11 de este manual para obtener más detalles)
9. Tecla de masaje manual: consulte la página 11 de este manual para obtener más detalles.
10. Tecla de rodillo de pie: consulte la página 11 de este manual para obtener más detalles.
11. Tecla de ajuste del hombro: ajuste manual de la posición del hombro humano para ubicar el punto de presión del dedo.
12. Tecla Arriba: Ajuste la elevación del marco del respaldo y la bajada del marco de la pantorrilla.
13. Tecla hacia abajo del marco de la pantorrilla: Ajuste el marco de la pantorrilla hacia abajo.
14. Tecla para acostarse: ajuste el marco del respaldo para que baje y el marco de las pantorrillas para que se eleve.
15. Tecla de intensidad de presión de aire: ajuste la función de intensidad de presión de aire.
16. Tecla de color: función de masaje con color encendido / apagado.

CARACTERÍSTICAS Y ASPECTOS DESTACADOS DEL PRODUCTO:

Uso de los modos de masaje

1. Encienda la fuente de alimentación

2. Empezar a masajear
①. Presione el botón de encendido para iniciar el masaje.
②. El marco de la pierna y el respaldo se ajustarán automáticamente al ángulo de acostado, esperando la selección de la función de masaje (seleccione una función automática). Si el ajuste de la postura sentada dura más de 3 minutos sin operación, se apagará automáticamente y regresará a la posición de sentado.
③. Después de seleccionar la función del modo automático, la detección automática de la posición del hombro humano y el punto de presión del dedo de masaje se llevará a cabo primero, y esperará a que se complete la detección.
④. Si la posición del hombro detectada se desvía de la posición real del hombro, ajuste con las teclas para arriba y abajo de la posición del hombro a la posición adecuada. Hay 10 posiciones predeterminadas para el hombro. Si no hay ajuste del hombro en 10 segundos, se iniciará automáticamente la función de masaje.

Button	Description	Display
▲	Mover los nodos de masaje hacia arriba a la posición adecuada	
▼	Mover los nodos de masaje hacia abajo a la posición adecuada	



Iniciar un proceso de detección de punto de acupresión y masaje de hombros, (cuando el dispositivo manual muestra el icono de ajuste de la posición del hombro y se escuche el sonido de "clic" del dispositivo manual, presione la tecla de posición del hombro adecuada), luego seleccione una de las 12 teclas de masaje automática (masaje cómodo, masaje relajante, masaje de tracción, masaje de hombros y cuello, masaje de espalda y cintura, masaje de cuerpo entero, masaje de protección vertebral, recuperación post-fatiga, estiramiento de músculos y activación de colaterales, modelador de glúteos, sueño relajante y presión de aire completo) y entra el paso 5.

⑤. Seleccione las funciones de masaje que desee.

Modos de masaje

-Masaje automático

Función	Botón	Descripción	Pantalla
Masaje Automático	Comfort	Confort: La experiencia de masaje más cómoda.	F1 Auto
	Relax	Fácil: La profundidad del masaje suave y cómodo, alivie la fatiga del cuerpo	F2 Auto
	Stretch	El marco y el respaldo se alzan y bajan con masaje por presión de aire y estirado o tracción en la pierna, elimine la fatiga, rejuvenecer la vitalidad	F3 Auto
	Pressure	Hombro y cuello: Masaje enfocado en los hombros y cuello	F4 Auto
	Backpat	Espalda y cintura: Masaje enfocado en la espalda y cintura	F5 Auto
		Masaje de cuerpo entero: masaje profundo que hace que su cuerpo se sienta más joven	A1 Auto
		Masaje quiropráctico: Masaje inspirado en la quiropraxia que relaja su mente y su cuerpo	A2 Auto
		Recuperación de la fatiga: Alivie el dolor por fatiga en todo el cuerpo, la espalda y las extremidades para lograr la relajación y mejorar la circulación	A3 Auto
	Warm	Masaje en Meridianos: Masaje de drenaje de los meridianos de la medicina tradicional China	A4 Auto
		Modelado de glúteos: Se enfoca entos lejidos adiposos redundantes acumulados en glúteos y muslos	A5 Auto
		Masaje para dormir tranquilamente: A través de los diez principales puntos de acupuntura, ayuda a mejorar la calidad del sueño	A6 Auto
		Presión Completa: se centra en el masaje de presión en todo el cuerpo, para relajarlo completamente y aliviar profundamente la fatiga y el dolor.	A7 Auto

- Masaje Manual del Cuerpo Superior

Función	Botón	Ajuste del Nodo de Masaje	Pantalla
Técnica	Modo	Shiatsu: velocidad, ancho	
		Knead: velocidad	
		Beat: velocidad, ancho	
		Knead pat: velocidad	
		Knock: velocidad, ancho	
Velocidad	Speed	Ajuste de 5 velocidades	
Ancho	Width	El ancho de la tercera velocidad puede ajustarse	
Estiramiento De la Espalda		Posición fija y masaje en un punto	H0
		Masaje en área local pequeña ida y vuelta	H1
		Un masaje de ida y vuelta	H2
	▲	Ajuste de la posición del masaje (en punto fijo y modo local, la posición del masaje puede ser ajustada)	Subir el nodo de masaje
	▼		Bajar el nodo de masaje

- Masaje Neumático

Función	Botón	Descripción	Pantalla
Modo de Presión de Aire	Air Pressure	Presión completa: masaje por presión de aire en brazos, piernas y pies	Arm Leg Foot
		Brazo: masaje por presión de aire enfocado en los brazos	Arm
		Pierna: Masaje barométrico para piernas y pies	Foot
Intensidad	Intensity	Ajustable en 3 niveles	Arm Leg Foot

-Masaje de Pies por Rodillos

Función	Botón	Descripción	Pantalla
Rodillos de Pies	Foot Roller	Presione este botón para seleccionar el masaje por rodillos en los pies y ciclar entre los ajustes de intensidad suave, medio, bajo y apagado	

- Calor con calor

Función	Botón	Descripción	Pantalla
Calor	Heating	Presione esta botón para encender o apagar el calor infrarrojo lejano. 3 minutos después de encenderlo se percibe el calor	

-Pause/start massage button

Función	Botón	Descripción	Pantalla
Pause/inicio	II	Durante el masaje presione esta botón y todos los movimientos serán suspendidos de inmediato (mientras el temporizador continúa la cuenta regresiva). Presione de nuevo esta tecla para reiniciar todas las funciones de masaje que estaban suspendidas	II

- Adjust Lying Angle

Función	Botón	Descripción
Sentarse		Al presionar esta botón, el respaldo lentamente se levantará y el marco de la pantorrilla lentamente descenderá y se emitirá un pitido hasta que llegue a la parte más alta. Presione esta botón de nuevo mientras está sentado para detener el movimiento
Recollar		Presione esta tecla y el respaldo lentamente descenderá y el marco de las pantorrillas lentamente se levantarán y se emite un pitido hasta que se detiene. Presione esta tecla de nuevo durante el proceso de recollarse para detener el movimiento.
Elevar Pantorrilla		Presionar y mantener presionado esta botón hace que el marco de la pantorrilla lentamente se levante y emita un pitido hasta que alcanza lo más alto y se detiene. El movimiento se detiene al soltar el botón
Bajar Pantorrilla		Presionar y mantener presionado esta botón hace que el marco de la pantorrilla lentamente descienda y emita un pitido hasta que alcanza lo más bajo y se detiene. El movimiento se detiene al soltar el botón
Recollar Automáticamente		Presione este botón siempre que desee cambiar a uno de los modos de recollado automático. Hay 3 modos.

-Other manual functions

Función	Botón	Descripción	Pantalla
Temporizador	Timer	Cada vez que se presiona esta botón se agregan 5 minutos al temporizador sin exceder de 30 minutos. Después de ello, el contador